



Acer Iconia B1-711 Microphone Replacement

Acer Iconia B1-711 Microphone Replacement

Written By: ZFix



INTRODUCTION

Follow this manual if you want to change a not working microphone.

[Please SUBSCRIBE to my channel ツ](#)

[video: <https://www.youtube.com/watch?v=8-djJ2aXa60>]

TOOLS:

- [Tweezers](#) (1)
 - [iFixit Opening Tools](#) (1)
 - [Spudger](#) (1)
-

Step 1 — Back Cover



- Switch-off the tablet.
 - Remove any SIM and/or Memory Card.
 - Start opening near to the Volume Up/Down buttons. It's more well to use a plastic opening tool to avoid damaging the cover.
- ⚠ When lifting the cover, be careful not to tear the Loudspeaker cable at the bottom right side.
- Disconnect the Loudspeaker cable from the Logic board.

Step 2



⚠ Before doing anything, disconnect the battery.

★ [Please SUBSCRIBE to my channel ツ](#)

Step 3 — Microphone



- Remove the tape from the microphone.
- Disconnect the Microphone wires and remove the Microphone.

★ [Please SUBSCRIBE to my channel ツ](#)

To reassemble your device, follow these instructions in reverse order.

